



Australian Government
Geoscience Australia

RICS


Rapid Inventory Collection System

Version number: **1.4.0**

Release date: **29 August 2011**

Author: **Nariman Habili**

GeoCat#: **72650**



Licence

User Manual



© Commonwealth of Australia (Geoscience Australia) 2011

With the exception of the Commonwealth Coat of Arms and where otherwise noted, all material in this publication is provided under a Creative Commons Attribution 3.0 Australia Licence (<http://creativecommons.org/licenses/by/3.0/au/>)

Software

Copyright © 2011 Commonwealth of Australia (Geoscience Australia).

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <http://www.gnu.org/licenses/>.

Contents

ACKNOWLEDGEMENTS	4
PEOPLE	4
THIRD-PARTY TOOLS AND LIBRARIES	4
OVERVIEW	5
OVERVIEW	5
INTRODUCTION	5
SOFTWARE COMPONENTS.....	6
HARDWARE COMPONENTS	6
INSTALLATION	8
BUILDING FROM SOURCE	8
BINARY INSTALLER	8
USING THE SOFTWARE	9
USER INTERFACE.....	9
STARTING RICS	10
TEST MODE.....	10
CREATING A NEW SESSION	11
OPENING A SESSION.....	12
CAMERA PROPERTIES.....	12
<i>Camera Names</i>	12
<i>Exposure</i>	13
<i>Gain</i>	14
<i>White Balance</i>	14
<i>Frame Rate</i>	15
<i>Packet Size</i>	16
NOTE PAD AND DAMAGE LEVEL SETTINGS	16
CAMERA OR NETWORK SWITCH DISCONNECTION	17
CHECKLIST FOR USING THE RICS SOFTWARE.....	18
APPENDIX A – SQLITE DATABASE FILE.....	19
APPENDIX B – NOTE PAD CSV FILE.....	20
REFERENCES	21

Acknowledgements

People

- RICS was developed by Nariman Habili (software development) and Neil Corby (hardware integration).
- The software was reviewed and tested by Frank Fu and Martin Wehner before release.
- The RICS and car icons and the front cover of this user manual were created by Adrian Yee.

Third-party tools and libraries

- wxWidgets was used without any modifications to develop the graphical user interface (GUI). wxWidgets is released under the wxWindows Licence found here: <http://www.wxwidgets.org/about/newlicen.htm>.
- The Boost C++ library was used without any modifications in the RICS source code. The Boost software licence can be found here: http://www.boost.org/LICENSE_1_0.txt
- The libjpeg-turbo library was used without any modifications to accelerate jpeg compression. libjpeg-turbo is released under the wxWindows Licence found here: <http://www.wxwidgets.org/about/newlicen.htm>.
- The JPEGWriter (C++ wrapper for libjpeg) written by Adrian Secord was used without any modifications to wrap libjpeg-turbo functions. The library is licensed under the Creative Commons Public Domain Licence found here: <http://creativecommons.org/licenses/publicdomain/>.
- The Visual Leak Detector library was used without any modifications to test for memory leaks. The library is licensed under GNU GPL, version 2.
- The SQLite library was used without any modifications to write GPS data to a SQLite database file. SQLite is in the public domain; its licence can be found here: <http://www.sqlite.org/copyright.html>
- The serial library for C++, written by Ramon de Klein, was used without any modifications for serial communication between the GPS receiver and the RICS software. The library is licensed under GNU LGPL, version 2.1.
- Some icons, designed by Mark James (<http://www.famfamfam.com/lab/icons/silk/>), were used. The icons are licensed under Creative Commons Attribution 2.5 Licence found here: <http://creativecommons.org/licenses/by/2.5/>.

Overview

Introduction

The Rapid Inventory Collection System (RICS) is used to capture and save geo-tagged digital imagery of built environments. Up to four high resolution cameras capture images that are then displayed on the RICS Graphical User Interface (GUI) and saved in the JPEG format. It is typically used for building and infrastructure damage assessment following a natural disaster.

RICS was deployed following the 2009 Victorian Bushfires, the 2010 Kalgoorlie and Christchurch Earthquakes, 2011 Brisbane floods and Tropical Cyclone Yasi to collect geo-tagged imagery of structures and buildings.

In particular, RICS:

- Complements and augments the detailed field damage assessments (house-to-house and structure-to-structure) currently undertaken during post-event impact assessments using hand-held Personal Data Assistants (PDAs);
- Provides a quick 'first-look' of the damage impact area to prioritise the worst-hit regions for detailed surveys;
- Permits 100% coverage of building damage in a disaster-affected area (provided vehicular access is available);
- Collects data focusing on 'population coverage' and in disaster situations quickly collects information on undamaged structures allowing engineering and GIS staff to focus on damaged structures; and
- Allows fieldwork (damage assessment) to be undertaken more efficiently.



RICS vehicle with two side cameras

At the end of a survey, geo-referenced JPEG imagery is available for analysis. At Geoscience Australia each property within the survey zone is attached to a RICS image. The damages to the properties are then ascertained from the images using GIS software.

Software Components

RICS is written in C++ using Microsoft Visual C++ Express 2008. wxWidgets, a GUI library, is used to implement the user interface. wxThreads, included in wxWidgets, is used to implement software threading. Image capture, image streaming (via the Ethernet network) and compression in the JPEG format are performed on a separate thread for each camera. The GPS data fetch and NMEA 0183 parsing is also performed on a separate thread. SQLite is used to store image file names and their corresponding GPS data, enabling images to be geo-referenced.

Hardware Components

RICS is designed to be a cost effective tool for capturing geo-tagged imagery of built environments. As such, off-the-shelf hardware is used to set up the system. At Geoscience Australia, the following hardware components are currently used:

- Mini tripods mounted on a motor vehicle with magnets;
- Camera configuration consisting of two, three or four Allied Vision Technologies (AVT) GC2450 GigE 5 megapixel digital cameras (2448 by 2050 pixels);
- Five port Gigabit Ethernet switch with jumbo frame support to network camera image streams (jumbo frames reduce the CPU load required to handle incoming data);
- Fujinon 16mm or 12.5mm focal length lenses;
- Swann 1020 camera housings providing all weather protection;
- An Intel® Core i5 laptop with 4 GB of RAM;
- Inverter to power laptop and network switch;
- GPS receiver; and
- Camera batteries.

The hardware components are assembled in the following order:

1. Attach tripods to the camera housings.
2. Attach power (from batteries) and Ethernet cables to the cameras.
3. Mount tripods on vehicle.
4. Attach Ethernet cables from the cameras to the network switch and attach the network switch to the power-board.
5. Attach Ethernet cable from the network switch to the laptop and attach the laptop's power supply to the power-board.
6. Attach the power-board to the inverter.
7. Attach the inverter to the auxiliary power source of the vehicle, making sure the inverter is switched off.
8. Attach the GPS receiver to a USB port of the laptop.
9. Turn on vehicle and turn on the inverter.

If you do not have camera batteries available, you can connect the camera's power supply to the power board.




Diagram showing the hardware setup, with numbers referring to the order above

Installation

Building from Source

The RICS source code and the binary installer is available from Google Code <http://code.google.com/p/rics/>. A Microsoft Visual 2008 VCPROJ file is provided. Please refer to the README.txt file for information on building and installing the software from source.

Binary Installer

Double click the self-install file rics-<version number>.msi. This will install RICS and the Allied Vision System (AVT) GigE Filter and GigE Viewer self-installation files. The installation of the Viewer and the Filter are optional but it is highly recommended that both are installed. The Viewer can be used to focus the cameras and set various camera parameters as it can display a larger view of the captured images than RICS. The Filter offloads some of the gigabit Ethernet data handling and reduces the CPU loading. For more information please visit the [Allied Vision Technologies](http://www.alliedvision.com) website.

To uninstall the software, follow the procedure below:

1. In the **Windows Control Panel** window, click **Add/Remove Programs**.
2. Highlight **Rapid Inventory Collection System** and click **Change/Remove** button.
3. Repeat step 2 for the AVT GigEViewer and Filter.

Using the Software

User Interface

RICS' user interface was designed to be user-friendly, consistent and intuitive. The main window consists of three sections, images, GPS data and notepad.

Streamed images are displayed in the top section while the GPS data displayed in the middle section includes the time (UTC), latitude, longitude, bearing, number of satellites, fix quality and speed. The speed, in kilometres per hour, is displayed prominently in a larger font. The bottom section notepad allows users to type notes during a field session. If a user wishes, the current time, latitude, longitude and bearing (heading) can be added to the end of each line, allowing the notes to be time and geo-referenced. The notepad text is saved as a 'comma separated value' file, and can therefore be opened in a database or spreadsheet program. The image below shows the RICS user interface in session mode with two cameras attached.



The RICS GUI

Starting RICS

The computer's Ethernet adapter will first need to be set up. Instructions are available from the AVT GigE Vision Cameras [Installation Manual](#).


Open RICS by clicking its icon  on the Windows Start Menu or double clicking the icon on your desktop. Please note that it will take about a minute for the cameras to register on the computer after the cameras and/or the network switch is turned on.

Test Mode


In Test Mode, images are not saved and a database is not created. Captured images are simply displayed on the GUI. Test Mode can be used to focus the cameras and set the correct camera properties before a session is created, images are saved and a database created.

At start-up, RICS is in Test Mode. If in Session Mode, click  or click **File** → **Test (Ctrl-T)** to enter Test Mode. To start capturing and displaying images, click  or click **Playback** → **Play (Ctrl-P)**. To stop, click  or click **Playback** → **Stop (Ctrl-S)**.

To display GPS data, the GPS receiver must be found. Click  on the toolbar or click **Options** → **GPS Properties (Ctrl-G)** and select the COM port that your GPS receiver is connected to on your computer using the drop-down menu.



If you're unsure which COM port your GPS receiver is connected to, click **Search Ports** and RICS will find the correct port.




The software parses the GPRMC and GPGGA sentences; your GPS receiver must supply those sentences. The following serial configuration is currently hardcoded in RICS:

Baud rate: 4800
Data bits: 8

Parity: None
Stop bits: 1

Creating a New Session

To create a session in RICS, open the New Session dialog box by clicking  or clicking **File** → **New Session (Ctrl-S)** and enter a session name (in the image below, the session name is Queanbeyan). The session will be located in the directory indicated by *Session Location*. To change the session location, click Browse or enter the location in the text box. The default location is C:\RICS Sessions.



A new session is created by clicking **OK**. Assuming the session location is 'C:\RICS Sessions' and two cameras are attached to the computer (with names L and R), the following directory structure and files will be created under C:\RICS Sessions:

```
C:\RICS Sessions\  
  Queanbeyan\  
    R\  
    L\  
    Queanbeyan.sdb  
    Queanbeyan.csv (only if the Note Pad is used)
```


If *Add GPS date/time* is checked, the date and time extracted from the GPS string is added to the end of the session name, e.g. Queanbeyan_200211_31139 (20 February 2011 at 03:11.39).

Images captured by camera 'R' are saved in C:\RICS Sessions\Queanbeyan\R and images captured by camera 'L' are saved in C:\RICS Sessions\Queanbeyan\L in the JPEG format starting with filename 0000000.jpg. 'Queanbeyan.sdb' is the SQLite database created by RICS and contains the tables 'R' and 'L'. To browse or modify the database manually, tools such as the [SQLite Database Browser](#) or the [Firefox SQLite add-on](#) can be used. Each row in the database corresponds to a captured image; e.g. image 0000023.jpg in directory 'R' corresponds to frame 23 in database table 'R'. See Appendix A for further information on the SQLite database.

If the session already exists (i.e. its directory structure exists), clicking **OK** simply opens that session. Images are saved from the last filename in each directory and data is entered into the database from the last entry. No images or database entries are overridden. **Note** that if extra cameras are attached to the Ethernet card, or if the camera names are changed, new directories and database tables are created to accommodate the new camera names.

Opening a Session

To open an existing session in RICS, open the *Browse for Folder* dialog box by clicking  or clicking **File** → **Open Session (Ctrl-O)**. Click on the directory containing the session folders/files and click *OK*. RICS is now in session mode. Note that the session directory must contain the associated database file, e.g. if the session is Queanbeyan, Queanbeyan.sdb must exist in directory Queanbeyan.




Camera Properties

Click  on the toolbar or click **Options** → **Camera Properties (Ctrl-C)** to open the *Camera Properties* dialog box.

Camera Names

Click the *Camera Name* tab on the *Camera Properties* dialog box. Each camera attached to the Ethernet switch has a unique camera ID and name. The camera IDs come from the camera and are fixed. Camera names are user changeable. The names represent the direction that a camera is pointing, as per the car image below (L = left, R = right, B = back, F = front). Upon start-up, the cameras are assigned default names.




To change a camera name, click on a camera ID and then select a camera name from the drop-down menu. Images are saved in directories named after the camera names and therefore each camera should be assigned a unique camera name, i.e. two cameras cannot have the same name.

Exposure

Click the *Exposure* tab on the *Camera Properties* dialog box. The exposure time (in milliseconds) can be changed manually by moving the slider; the current exposure time is displayed in the text box. Alternatively, auto-exposure can be chosen by checking *Auto*. *Auto Max Time* sets the maximum exposure time for auto-exposure.

If *Apply to camera* is unchecked, exposure time changes apply to all cameras. Individual cameras can be selected by checking *Apply to camera* and selecting a camera from the drop-down menu. Press Enter or click *OK* if closing the dialog box.




It has been found that setting the exposure time to *Auto* and setting an *Auto Max Time* of 5 ms gives the best exposure results. A maximum exposure time is useful to avoid a long exposure time which can result in blurry images.

Gain

Click the *Gain* tab on the *Camera Properties* dialog box. The camera gain, in dB, can be changed by moving the slider; the current gain value is displayed in the text box. A gain value can also be typed in the text. Alternatively, auto-gain can be chosen by checking *Auto*. The default gain value is zero, which gives the best image quality. In low light situations, it may be necessary to increase the gain setting.


If *Apply to camera* is unchecked, gain changes apply to all cameras. Individual cameras can be selected by checking *Apply to camera* and selecting a camera from the drop-down menu. Press *Enter* or click *OK* if closing the dialog box.



White Balance

Click the *White Balance* tab on the *Camera Properties* dialog box. The red channel or the blue channel gains as a per cent relative to green channel can be changed by moving the sliders; the current gain values are displayed in the text boxes. A gain value can also be typed in the text box. Alternatively, you can choose auto-white balance by checking *Auto*.


If *Apply to camera* is unchecked, white balance changes apply to all cameras. Individual cameras can be selected by checking *Apply to camera* and selecting a camera from the drop-down menu. Press *Enter* or click *OK* if closing the dialog box.



White balance can be used to remove unrealistic colour casts from the images. The default values of Red = 181 and Blue = 202 was found to be the most suitable.

Frame Rate

Click the *Frame Rate* tab on the *Camera Properties* dialog box. Change the frame rate in frames per second by moving the slider so that the current frame rate setting is displayed in the text box. The frame rate can also be typed in the text box. Press *Enter* or click *OK* if closing the dialog box.




Field trials suggested that four consecutive frames are necessary to capture an entire house with an average frontage of 20 metres using 12.5 mm lenses. With two cameras attached to the laptop, the maximum frame rate is four frames per second for a GigE 5 megapixel camera. This suggests a maximum vehicle speed of 72 km/h. However, to reduce the

chances of image blur, especially on overcast days, the Geoscience Australia RICS survey vehicle is driven at a maximum speed of 40 km/h.

Packet Size


Click the *Packet Size* tab on the *Camera Properties* dialog box. Change the packet size in bytes by moving the slider; the packet size is displayed in the text boxes. The packet size can also be typed in the text box. The selected packet size must not exceed the maximum packet size supported by the Ethernet card (see the AVT GigE Vision Cameras [Installation Manual](#) for more information), otherwise RICS may become unstable. Please note that the packet size cannot be changed if RICS is in the play mode. Press Enter or click *OK* if closing the dialog box.



Note Pad and Damage Level Settings

The note pad is enabled only if RICS is in Session Mode. A message can be typed in the note pad and Enter pressed. Pressing Enter will save the note pad file in the CSV (comma separated value) format with filename <session name>.csv. The typed messages can be time and geo-referenced. To enable this, click **Options** → **Damage Level Settings (Ctrl-D)** to open the *Damage Levels Settings* dialog box (image below) and check *Add time, latitude, longitude and bearing at the end of each line*. **Note** that RICS automatically adds the header 'comment,time,lat,lon,bearing' to enable reading of the CSV file in a database. More information on the CSV file is available in Appendix B.

Predefined damage levels can also be added to the note pad by checking *Use predefined damage levels* in the *Damage Levels Settings* dialog box either by opening a text file containing pre-defined damage levels or by typing damage levels at F2 – F9. If a text file is opened, the first eight lines of the file are assumed to represent the eight pre-defined damage levels. The current damage levels are shown in F2 – F9. If the damage levels are modified and the dialog box is closed (either by clicking *OK* or *X* in the upper right corner) a prompt indicates that the damage levels have changed and whether the new levels are to be saved. To add a damage level to the notepad, use keys F2 – F9, which also saves the text file.



Camera or Network Switch Disconnection


If a camera or the network switch is turned off or is disconnected from the computer, RICS will attempt to close gracefully instead of crashing. That is, any remaining captured images are saved, the SQLite database is closed, the notepad is saved and all threads are deleted as per normal. If RICS does close because of a camera or network switch disconnection, it is a good idea to check that the Note Pad CSV and the SQLite database files have closed properly.

Checklist for Using the RICS Software

1. Open the AVT GigEViewer.
2. Turn on the cameras and wait for the cameras to register on the GigEViewer. This should take about one minute.
3. Focus the cameras and close the GigEViewer.
4. Open RICS.
5. Make sure all cameras are present and viewable in Test Mode after clicking  or clicking **Playback** → **Play (Ctrl-P)**.
6. Set exposure on auto (for all cameras), check white balance, frame rate, and packet size.
7. Find GPS device and check GPS output.
8. Click  to start a new session. Enter a new session name and click *OK*.
9. If the session already exists, click  to open a session. Click on a directory (containing all session files/directories) and click *OK*.
10. Click *Option*, and click *Damage Level Settings*. Check *Use predefined damage levels* and browse to a text file containing the damage levels. Click *OK*.
11. Click  or **Playback** → **Play (Ctrl-P)** when ready to record. The icon will blink indicating that the captured images are being saved.
12. Click  or click **Playback** → **Stop (Ctrl-S)** to stop recording.
13. To close the software, click **File** → **Quit (Ctrl-Q)** or click the *X* in the top hand corner of the window.

Appendix A – SQLite Database File

The figure below shows the 'R' table and its fields in SQLite Database Browser. The fields are frame, GPS time, latitude, longitude, speed (km/h), bearing (or heading), satellites, fix quality and camera ID. Frame refers to the JPEG image file. That is, frame 288 refers to file 0000288.jpg. Satellites refers to the number of satellites in view of the GPS receiver. The number of satellites and the fix quality can be used to check the veracity of the collected data.



SQLite Database Browser - C:\RICS Sessions\Qeanbeyan\Qeanbeyan.sdb

File Edit View Help

Database Structure Browse Data Execute SQL

Table: R


frame	time	latitude	longitude	speed	bearing	satellites	fix_quality	camera_ID	
289	288	32251	-17.89803	145.926792	32.7	263.6	10	2	53086
290	289	32251	-17.89803	145.926792	32.7	263.6	10	2	53086
291	290	32252	-17.898037	145.926708	31.7	267.3	10	2	53086
292	291	32252	-17.898037	145.926708	31.7	267.3	10	2	53086
293	292	32252	-17.898037	145.926708	31.7	267.3	10	2	53086
294	293	32253	-17.898038	145.926627	30.6	270.7	10	2	53086
295	294	32253	-17.898038	145.926627	30.6	270.7	10	2	53086
296	295	32253	-17.898038	145.926627	30.6	270.7	10	2	53086
297	296	32253	-17.898038	145.926627	30.6	270.7	10	2	53086
298	297	32254	-17.898037	145.926547	29.1	272.0	10	2	53086
299	298	32254	-17.898037	145.926547	29.1	272.0	10	2	53086
300	299	32254	-17.898037	145.926547	29.1	272.0	10	2	53086
301	300	32254	-17.898037	145.926547	29.1	272.0	10	2	53086
302	301	32255	-17.898035	145.926473	27.4	271.5	10	2	53086
303	302	32255	-17.898035	145.926473	27.4	271.5	10	2	53086
304	303	32255	-17.898035	145.926473	27.4	271.5	10	2	53086
305	304	32255	-17.898035	145.926473	27.4	271.5	10	2	53086
306	305	32256	-17.898037	145.926403	25.0	266.1	10	2	53086
307	306	32256	-17.898037	145.926403	25.0	266.1	10	2	53086
308	307	32256	-17.898037	145.926403	25.0	266.1	10	2	53086
309	308	32256	-17.898037	145.926403	25.0	266.1	10	2	53086
310	309	32257	-17.898045	145.926345	20.6	255.6	10	2	53086
311	310	32257	-17.898045	145.926345	20.6	255.6	10	2	53086
312	311	32257	-17.898045	145.926345	20.6	255.6	10	2	53086

1 - 1000 of 2930

Go to: 0

Appendix B – Note Pad CSV File

Information entered in the Note Pad section of the GUI is saved in the CSV format. An example CSV file opened in Microsoft Excel is shown below. As the file is in the CSV format, it is important that the comment text does not include any commas, because commas indicate a new field. The file can be opened in GIS software for processing.



	A	B	C	D	E	F
1	comment	time	lat	lon	bearing	
2	Missle to Cladding	32253	-17.99803	145.825654	81.3	
3	Loss of all Roof Sheeting	32623	-17.99804	145.826545	34.1	
4	Loss of Half Roof Sheeting	33112	-17.99403	145.245654	43.5	
5	Missle to Cladding	34423	-17.99703	145.824675	272.8	
6	Negligible	34854	-17.989603	145.854454	67.5	
7	Loss of Half Wall	35321	-17.933503	145.828745	263.6	
8						

References

N. Habili, N. Corby, and B. Cechet, *Rapid Inventory Collection System (RICS) and the 2009 Victorian Bushfires Impact Assessment*, In 2010 IOP Conf. Ser.: Earth Environ. Sci., vol. 11 num. 1. (http://iopscience.iop.org/1755-1315/11/1/012018/pdf/1755-1315_11_1_012018.pdf)

N. Habili, N. Corby, and B. Cechet, *Rapid Inventory Collection System (RICS) and the 2009 Victorian Bushfires*, In Industry Stream Proc. 21st Australian Software Engineering Conference, Auckland, New Zealand, April 2010.

AVT GigE Vision Cameras Installation Manual,
http://www.alliedvisiontec.com/fileadmin/content/PDF/Products/Technical_Manual/GigE_Installation_Manual/70-0062_GigE_Installation_Manual_V2.0.pdf.